

UFI OPERATION

To enable wireless DMX operation via the optional UFI wi-fi transceiver:

- 1) Set the ULTRA PAR starting DMX address
- 2) Set the UFI sending/receiving channel
- 3) Attach the UFI to the ULTRA PAR USB port
- 4) Use Dipswitch 5 to select UFI send or receive mode.

